



Command Intercom System


P-3131/ P3132 Remote Master Quick Guide

Overview


This document is intended for users of the CIS P-3131/P-3132 Remote Master Stations. For further information, see A100K11942 - User Handbook CIS 313X vXX.

Preparation before power-up and setting to work

Before power-up, the Remote Station must be configured according to the requirements. A selection of jumpers and DIP-switches placed inside the unit, jumpers on the lower Main board and DIP-switches on the upper piggyback accessory ADD-ON BOARD F.CIS. The configuration of these decides the operation and how the system behaves. In order to access the jumpers on the main board it is necessary to temporarily remove the piggyback board. It is important that the setting above is harmonized with the Master Station P-3130, except settings that are only affecting the Remote locally.



Main Board:




J3 Terminal / pin No. - J3 Terminal / pin. nr.	Function / Equipment	Funksjon / tilkoblet utstyr
1 & 2	Volume potensiometer	Volum potensiometer
3 & 4	Unit loudspeaker	Apparat høyttaler
5 & 6	Microphone	Mikrofon element
7 & 8	TALK activator	Tale knapp

Strap	Condition Tilstand	Description / Functionality Beskrivelse / Funksjon	Standard
ST2 ST1 • •---•	ST1 closed ST2 open <i>ST1 lukket ST2 åpen</i>	Using an additional microphone, the integrated microphone is not used <i>Benytter tilleggsmikrofon, integrert mikrofon benyttes ikke</i>	
ST2 ST1 •---• •	ST1 open ST2 closed <i>ST1 åpen ST2 lukket</i>	Using the integrated microphone, an additional unit microphone is not mounted <i>Benytter integrert mikrofon, tilleggsmikrofon på enheten er ikke montert</i>	✓
ST3 • •	ST3 open <i>ST3 åpen</i>	Starboard bridge wing interface is used as bridge wing interface - NORMAL <i>Styrbord broving interface benyttes som broving - NORMAL</i>	✓
ST3 •---•	ST3 closed <i>ST3 lukket</i>	Starboard bridge wing interface is used as input for external PRIORITY ALL CALL <i>Styrbord broving interface benyttes som inngang for eksternt PRIORITERT ALLE KALL</i>	
ST4 • •	ST4 open <i>ST4 åpen</i>	Microcontroller RESET: Always open during normal working conditions <i>Mikrokontroller RESET: Skal alltid være åpen i normal drift</i>	✓
ST4 •---•	ST4 closed <i>ST4 lukket</i>	Only to be used by service personnel: Always open during normal working conditions <i>Benyttes kun av service personell: Skal alltid være åpen i normal drift</i>	
ST5 • •	ST5 open <i>ST5 åpen</i>	Disable loudspeaker audio to the starboard bridge wing interface. This facility is used in line feed conditions. i.e PA-system, PABX etc. <i>Frakoble høyttaler audio til styrbord broving interface. Benyttes ved tilkobling til eksternt nøklingsutstyr f.eks. PA-system, PABX etc.</i>	
ST5 •---•	ST5 closed <i>ST5 lukket</i>	Enable loudspeaker audio to the starboard bridge wing. This facility is used in NORMAL bridge wing operation <i>Tilkoble høyttaler audio til styrbord broving. Benyttes ved NORMAL broving funksjon</i>	✓
ST7 ST6 • •---•	ST6 closed- ST7 open <i>ST6 lukket- ST7 åpen</i>	The starboard bridge wing is connected to a line level (0dBm) interface, i.e. PA system, PABX etc. <i>Styrbord broving er tilkoblet linje nivå (0dBm) interface. F.eks. PA system, PABX etc.</i>	
ST7 ST6 •---• •	ST6 open- ST7 closed <i>ST6 åpen- ST7 lukket</i>	The starboard bridge wing is connected to a microphone level interface, i.e. bridge wing microphone, microphone for PRIORITY ALL CALL <i>Styrbord broving er tilkoblet mikrofon nivå interface, f.eks. broving mikrofon, mikrofon for PRIORITERT ALLE KALL</i>	✓

ADD-ON BOARD FCIS

•As a general rule the ST jumper shall be open in most Remote stations P-3131/P-3132. However, if the system consists of many Remotes, the data communication line can be too long and jam the signals. In this case the jumper can be closed on one (preferably the farthest) remote or more.

The DIP Switch 8 shall always be in the ON position.



Power-up and connecting the system

The Remote station does not contain terminals for substations, all substations are to be terminated at the Master Station P-3130.

On the Remote Station P-3131/P-3132, there are terminals for:

- The Remote station's own external signal device
- Serial communication bus to the Master Station and all other All Remote stations (Daisy chained serial connection) – consisting of 1 Pair serial data, - 1 Pair Audio, 1 Pair power (24VDC)
- External unit loudspeaker
- Port and Starboard (Multi-purpose) Bridgewing Microphones/Loudspeakers
- Power & GND

Operation

The Remote Station is equipped with 15 pushbuttons for substation line selection, one pushbutton for Master and 4 pushbuttons for up to 4 Remote stations. In Idle state the Master pushbutton led indicator lights yellow. This indicates that no Remotes are "IN COMMAND" and all substation calls will come to the Master Station only. By activating your own Remote button, you put yourself "IN COMMAND". This function will remain until the Master or other Remotes activate their own station button and thus take over the "IN COMMAND" status. Calling the Master or other Remotes can be done by activating the related pushbutton and press either the "TALK" or the "SIGNAL" button.

Each Substation pushbutton has a bi-colored LED indicator (Green and Orange) The Green indicator shows incoming calls. The Orange indicator lights when a substation line is selected. If the Master Station is idle when a substation is calling, the Call tone is sounded. If the unit is busy only the indicator is lit.

If the "Busy Tone" sounds it indicates that the Master is busy. A way to interrupt this situation is to activate the "IN COMMAND" function. This will immediately update the Remote to the ongoing activity and make the Remote able to join and/or take control.

Further, the unit is equipped with a TALK button for Simplex operation. If operated when no line selection has been pre-selected an ALL-CALL public Address message is made.


The SIGNAL button generates a call signal to selected stations and substation lines.

The unit also contains both an integrated microphone and Loudspeaker for two-way communication.

Further Information

This document is intended for users of the 15 lines +4 Remote Master CIS P-3130 Master Station.

For further information, see A100K11942 - User Handbook CIS 313X vXX.





Hear, be heard, and be understood
– every time and everywhere

DOC.NO.

Date 9.01.24

A100K12305

cs@zenitel.com

Zenitel and its subsidiaries assume no responsibility for any errors that may appear in this publication, or for damages arising from the information therein. Zenitel, Vingtor-Stentofon and Phontech products are developed and marketed by Zenitel. The company's Quality Assurance System is certified to meet the requirements in NS-EN ISO 9001. Zenitel reserves the right to modify designs and alter specifications without notice. ZENITEL PROPRIETARY. This document and its supplementing elements contain Zenitel or third-party information which is proprietary and confidential. Any disclosure, copying, distribution or use is prohibited, if not otherwise explicitly agreed in writing with Zenitel. Any authorized reproduction, in part or in whole, must include this legend: Zenitel – All rights reserved.