VINGTOR STENTOFON

Replacing Access Panel ECPIR

Item Number	Item Name	Description
102 3200 030	ECPIR-P	Exigo Access Panel, PTT Button
102 3200 033	ECPIR-3P	Exigo Access Panel, PTT + 3 Buttons

#	Label
1	Loudspeaker
2	Label insertion slot
3	Label window
4	Status indicators
5	PTT button
6	Backlight control
7	Volume control
8	Screw hole
9	Button protection
10	Function indicators
11	Function button
12	Microphone connector

1   Demounting the Old Access Panel

To demount the access panel:

1. Disconnect the access panel from the power supply, microphone, I/O interface and network cables.
2. Remove the four screws that attach the access panel to the mounting box or console.
3. Lift the access panel out of the mounting box or console.

2   Mounting the New Access Panel

To mount the access panel:

1. Insert the access panel into the mounting box or console.
2. Fasten the access panel to the mounting box or console with the four screws.
3. Reconnect the access panel to the power supply, microphone, I/O interface and network cables.

To set up the access panel:

1. Power up the access panel by connecting it to a PoE network.

2. Wait for the **yellow Fault LED to start flashing**, indicating that the access panel has been booted up successfully.

3. Press any button to make the access panel speak its IP address.

4. Access the IP address through a web browser on a PC that is connected to the same network as that of the access panel.

5. Log in with username: **admin** and password: **alphaadmin**

6. Select **Station Main** > **Main Settings**

7. Change the **Domain Controller IP** address, **Directory Number**, **IP-address**, **Subnet-mask**, and **Gateway** to ones specified for the project.

8. Click **Save**